

Onehand flute by flutelab. Instructions for use.



Place the case on a flat surface before opening. The "flutelab" sign must face up.

First put up the stand, if you are using one.



The feet must stand wide. Tighten knob well.



This is too small. The stand may topple.



This is dangerous. The steel part will not hold and the flute will fall.




This is better.



Do tighten the brass handle well. After playing, remove the flute and loosen the handle. The plastic clamp piece will loose its shape if you keep the pressure on it.

Adjust the height of the stand. The white knob on the top of the stand must be the height of your chin. Make sute all knobs are tight.



Push the headjoint on the flute. Do not grip the flute by the keys as they are very fragile.



This is how the headjoint is rotated. The crown (that is the knob on the end of the headjoint) sits over the longest rods.



Place the flute on the stand. It can only go one way. Tighten the knob. You are ready to play!

1 and 2 nd octave C #### #C 8ve	The fingering table is in the case. If you need another one you can download from my website flutelab.com of just email me and I will send you one flutelab@gmail.com.
To remove the headjoint, push it out bit by bit. You can use the flute in the foam insert inside the case.	The footjoint stays on all the time. Do not rotate the footjoint.
Dry the flute after playing with the swab supplied.	